

GESTRA Steam Systems

LRGT 16-1

LRGT 16-2

LRGT 17-1

EN
English

Installation Instructions 818726-03

Conductivity Transmitter LRGT 16-1

Conductivity Transmitter LRGT 16-2

Conductivity Transmitter LRGT 17-1

Contents

Page

Important Notes

| | |
|---|---|
| Usage for the intended purpose | 4 |
| Safety Note | 4 |
| Danger | 4 |
| ATEX (Atmosphère Explosible) | 4 |
| Note on the Declaration of Conformity / Declaration by the Manufacturer CE | 4 |

Explanatory Notes

| | |
|-----------------------|---|
| Scope of supply | 5 |
| Description | 5 |
| Function | 6 |

Technical Data

| | |
|---------------------------------------|---------|
| LRGT 16-1, LRGT 16-2, LRGT 17-1 | 7, 8 |
| Name plate / marking | 9 |
| Dimensions | 10 – 12 |
| Key | 14 |

Functional Elements

| | |
|---------------------------------------|----|
| LRGT 16-1, LRGT 16-2, LRGT 17-1 | 13 |
| Key | 14 |

Installation

| | |
|---|----|
| Installation notes | 15 |
| Attention | 15 |
| Note | 15 |
| Mounting conductivity transmitter | 15 |

Examples of Installation

| | |
|--------------------------------|--------|
| Examples of installation | 16, 17 |
| Key | 17 |
| Tools | 17 |

Electrical Connection

| | |
|--|--------|
| LRGT 16-1, LRGT 16-2, LRGT 17-1 | 18 |
| Connecting the conductivity transmitter | 18, 19 |
| Key | 10 |
| Safety power supply unit for LRGT 16-1, LRGT 16-2, LRGT 17-1 | 20 |
| Tools | 20 |
| Wiring diagram for conductivity transmitter LRGT 16-1, LRGT 17-1 | 20 |
| Wiring diagram for conductivity transmitter LRGT 16-2 | 21 |

Basic Settings

| | |
|--|--------|
| Factory setting | 22 |
| Establishing measuring range and actual value output | 22, 23 |
| Checking temperature coefficient setting T_k | 24 |

Commissioning Procedure

| | |
|--------------------------------------|----|
| Checking electrical connection | 25 |
| Applying mains voltage..... | 25 |
| Note | 25 |

Operation

| | |
|--|----|
| Correcting the measured value | 26 |
| Checking the temperature coefficient setting T_k | 26 |
| Adapting cell constant | 26 |
| Functional test..... | 27 |
| LEDs and malfunction indication..... | 27 |

Malfunctions

| | |
|---|--------|
| Fault-finding list for troubleshooting..... | 28, 29 |
| Cleaning the measuring electrode..... | 29 |
| Exchanging the electronic insert | 30 |
| Note | 30 |

Decommissioning

| | |
|---|----|
| Danger | 31 |
| Exchanging the conductivity transmitter | 31 |
| Disposal..... | 31 |

Important Notes

Usage for the intended purpose

Use conductivity transmitters LRGT 16-1, LRGT 16-2 and LRGT 17-1 only for measuring the electrical conductivity in liquids.

When used for conductivity limiting or continuous boiler blowdown in steam boilers the conductivity transmitters LRGT 16-1, LRGT 16-2 and LRGT 17-1 must only be used in conjunction with the industrial controller KS 90-1.

To ensure trouble-free operation the requirements made on water quality according to TRD and EN regulations must be met.

Use the equipment only within the specified pressure and temperature ratings.

Any type of use differing from the usage described above is considered as improper. The resulting risk will have to be borne by the user alone. The manufacturer hereby expressly rejects any claims for any resulting damage.

Safety note

The equipment must only be installed and commissioned by qualified and competent staff. Retrofitting and maintenance work must only be performed by qualified personnel who – through adequate training – have achieved a recognised level of competence.



Danger

When loosening the conductivity transmitter steam or hot water might escape. This presents the danger of severe scalding. It is therefore essential not to remove the conductivity transmitter unless the boiler pressure is verified to be 0 bar.

The conductivity transmitter becomes hot during operation. This presents the risk of severe burns to hands arms when the equipment is touched.

Installation, de-installation and maintenance work should only be carried out when the system is cold.

ATEX (Atmosphère Explosible)

According to the European Directive 94/9/EC the equipment must **not** be used in explosion risk areas.

Note on the Declaration of Conformity / Declaration by the Manufacturer

For details on the conformity of our equipment according to the European Directives see our Declaration of Conformity or our Declaration of Manufacturer.

The current Declaration of Conformity / Declaration of Manufacturer are available in the Internet under www.gestra.de/documents or can be requested from us.

Explanatory Notes

Scope of supply

LRGT 16-1

- 1 Conductivity transmitter LRGT 16-1
- 1 Joint ring 33 x 39, form D, DIN 7603, 1.4301, bright annealed
- 1 Installation manual

LRGT 16-2

- 1 Conductivity transmitter LRGT 16-2
- 1 Joint ring 33 x 39, form D, DIN 7603, 1.4301, bright annealed
- 1 Installation manual

LRGT 17-1

- 1 Conductivity transmitter LRGT 17-1
- 1 Joint ring 33 x 39, form D, DIN 7603, 1.4301, bright annealed
- 1 Installation manual

Description

The compact-design **conductivity transmitter LRGT 16-1, LRGT 16-2, LRGT 17-1** consists of a conductivity electrode, a temperature sensor for detecting the fluid temperature and a conductivity transmitting unit incorporated in the terminal box.

The conductivity transmitters LRGT 16-1 and LRGT 17-1 work according to the conductometric measuring method using **two** measuring electrodes and the conductivity transmitter LRGT 16-2 works according to the conductometric measuring method using **four** measuring electrodes. The equipment measures the conductivity of electrically conductive fluids (TDS content) and provides a 4-20 mA measuring current as a function of the detected conductivity value.

The conductivity transmitters are designed for use with the **industrial controller KS 90-1** for conductivity limiting and continuous boiler blowdown in steam boilers or for conductivity monitoring in condensate and feedwater systems.

The conductivity transmitters LRGT 16-1, LRGT 17-1 are mainly used in steam boilers with low TDS content, e.g. steam regenerators, high-pressure boilers or condensate tanks.

The conductivity transmitter LRGT 16-1 is also approved for feedwater monitoring on strips.

The conductivity transmitter LRGT 16-2 is mainly used in industrial boiler plants operating with pressures up to PN 40 and max. admissible conductivities acc. to TRD/EN of 8000/6000 $\mu\text{S/cm}$.

Function

LRGT 16-1, LRGT 17-1

A measuring current of variable frequency passes through the fluid, creating a potential gradient between the measuring electrode and the reference tube which is then used as measuring voltage U_U .

LRGT 16-2

The conductivity electrode consists of two current and two voltage electrodes. The current electrodes direct the measuring current I_I with a fixed frequency into the fluid, thereby creating a potential gradient between these electrodes. This potential difference is then picked up by the voltage electrodes and evaluated as measuring voltage U_U .

LRGT 16-1, LRGT 17-1 und LRGT 16-2

The electrical conductivity is a function of temperature. A resistance thermometer integrated in the electrode measures the fluid temperatures so as to relate the measured values to the reference temperature.

The electrical conductivity is calculated from the measuring voltages U_U and U_I and – as a function of the adjusted temperature coefficient T_k – linearly based on the reference temperature of 25 °C. Once converted into a conductivity-dependent current signal, an output current of 4 – 20 mA is available for external use.

The cables leading to the measuring electrode, the reference tube and the resistance thermometer are monitored and checked for interruptions and short circuits. In addition, the circuit board is protected against excess temperatures in the terminal box. In the event of a malfunction, the LEDs on the circuit board will light up or flash and the current signal is set to 0 or 0.5 mA. As a consequence the controller KS 90-1 will signal sensor break.

A ten-pole code switch enables the parameterisation of the transmitter, the adaptation of the cell constant and the activation of a performance test. The electrical conductivity is measured in $\mu\text{S}/\text{cm}$. In some countries the unit ppm (parts per million) is used (conversion: $1 \mu\text{S}/\text{cm} = 0.5 \text{ ppm}$).

Technical Data

LRGT 16-1, LRGT 16-2, LRGT 17-1

Type approval

TÜV.WÜL.xx-003
GL 33254-06 HH

Service pressure

LRGT 16-1: 32 bar at 238 °C
LRGT 16-2: 32 bar at 238 °C
LRGT 17-1: 60 bar at 275 °C

Connection

Screwed 1" BSP (ISO 228-1)

Materials

Electrode screw-in body: 1.4571, X6CrNiMoTi17-12-2
Measuring electrode(s): 1.4571, X6CrNiMoTi17-12-2
Electrode insulation: PTFE
Terminal box: 3.2161 G AISi8Cu3
LRGT 16-1, LRGT 17-1: measuring tube/screw: 1.4571, X6CrNiMoTi17-12-2
LRGT 16-1, LRGT 16-2: spacer disk: PEEK
LRGT 17-1: spacer disk: PEEK HT

Measuring length and length of installation (do **not** cut electrode tips!)

200, 300, 400, 500, 600, 800, 1000 mm (max. 400 mm for marine applications)

Temperature sensor

Resistance thermometer Pt 1000

Measuring cycle

1 sec.

Temperature compensation

Linear, T_k adjustable via code switch

- 0 % per °C
- 1.6 – 3.0 % per °C in steps of 0.1

Time constant (measured according to two-bath process)

Temperature: 9 sec.

Conductivity: 14 sec.

Indicators and adjustors

Two LEDs for status messages

One 10-pole code switch for setting:

- measuring range
- temperature coefficient
- cell constant
- functional test

Voltage supply

24 V DC (18-36 V DC)

Power consumption

4.5 watt

Fuse

Electronic thermal fuse $T_{max} = 85$ °C, hysteresis – 2 K

LRGT 16-1, LRGT 17-1

| Measuring range*) ($\mu\text{S/cm}$ at 25 °C) | | Current output mA = $\mu\text{S/cm}$ | |
|---|-------|--------------------------------------|----------------------|
| Preferred measuring range to 500 $\mu\text{S/cm}$ | | 4 mA corresponds to | 20 mA corresponds to |
| 0.5 | 20 | 0.5 | 20 |
| | 100 | | 100 |
| | 200 | | 200 |
| | 500 | | 500 |
| | 1000 | | 1000 |
| | 2000 | | 2000 |
| | 6000 | | 6000 |
| | 12000 | | 12000 |

LRGT 16-2

| Measuring range*) ($\mu\text{S/cm}$ at 25 °C) | | Current output mA = $\mu\text{S/cm}$ | |
|--|-------|--------------------------------------|----------------------|
| | | 4 mA corresponds to | 20 mA corresponds to |
| 100 | 3000 | 100 | 3000 |
| | 5000 | | 5000 |
| | 7000 | | 7000 |
| | 10000 | | 10000 |

Adjustable via code switch. Max. load for actual value output 750 ohm.
 *) **Conversion** of $\mu\text{S/cm}$ in ppm (part per million): 1 $\mu\text{S/cm}$ = 0.5 ppm

Cable entry

EMC cable gland with integrated cable clamp, M 20 x 1.5
 5-pole screw-type terminal strip, detachable, conductor size 1.5 mm²

Protection

IP 65 to EN 60529

Admissible ambient temperature

Max. 70 °C

Storage and transport temperature

-40 to +80 °C

Weight

Approx. 2.5 kg

Name plate / marking











| | | | | | | | | | | |
|--|---|--|--------------|----------------|---|---|---------|-------|------------|----------------|
|  <p>Betriebsanleitung beachten See installation instructions Voir instructions de montage</p> | <p>Safety note</p> |  <p>Betriebsanleitung beachten See installation instructions Voir instructions de montage</p> | | | | | | | | |
| <p>LRGT 16-1</p> <p>Leitfähigkeitstransmitter Conductivity Transmitter Transmetteur de mesure de conductibilité</p> | <p>Equipment designation</p> | <p>LRGT 16-2</p> <p>Leitfähigkeitstransmitter Conductivity Transmitter Transmetteur de mesure de conductibilité</p> | | | | | | | | |
| <p>PN40 G1 1.4571 IP65</p> | <p>Pressure rating, screwed connection, material number</p> | <p>PN40 G1 1.4571 IP65</p> | | | | | | | | |
|  <p>32 bar (464psi) 238°C (460°F)</p>  <p>Tamb = 70°C (158 °F)</p> | <p>Application specifications</p> |  <p>32 bar (464psi) 238°C (460°F)</p>  <p>Tamb = 70°C (158 °F)</p> | | | | | | | | |
| <table border="1"> <tr> <td>24 V DC</td> <td>4,5 W</td> </tr> <tr> <td>0,25-6000ppm</td> <td>0,5-12000µS/cm</td> </tr> </table> | 24 V DC | 4,5 W | 0,25-6000ppm | 0,5-12000µS/cm | <p>Electric rating</p> <p>Measuring range</p> | <table border="1"> <tr> <td>24 V DC</td> <td>4,5 W</td> </tr> <tr> <td>50-5000ppm</td> <td>100-10000µS/cm</td> </tr> </table> | 24 V DC | 4,5 W | 50-5000ppm | 100-10000µS/cm |
| 24 V DC | 4,5 W | | | | | | | | | |
| 0,25-6000ppm | 0,5-12000µS/cm | | | | | | | | | |
| 24 V DC | 4,5 W | | | | | | | | | |
| 50-5000ppm | 100-10000µS/cm | | | | | | | | | |
| <p>OUT: 4-20 mA / 750 Ω</p> | <p>Specification of actual value output</p> | <p>OUT: 4-20 mA / 750 Ω</p> | | | | | | | | |
| <p>TÜV.WÜL. 06-003 GL 33254-06-HH</p>  | <p>CE marking</p> | <p>TÜV.WÜL. 06-003</p>  | | | | | | | | |
| <p>GESTRA AG Münchener Str. 77 D-28215 Bremen</p>  | <p>Disposal note</p> <p>Manufacturer</p> | <p>GESTRA AG Münchener Str. 77 D-28215 Bremen</p>  | | | | | | | | |
| <p>VS-Nr.: 00 Mat-Nr.:392083</p> | <p>Spare part specifications</p> | <p>VS-Nr.: 00 Mat-Nr.:392409</p> | | | | | | | | |

Fig. 1

Dimensions




Fig. 2 LRGT 16-1




Fig. 3 LRGT 17-1




Fig. 4 LRGT 16-2

Functional Elements

LRGT 16-1, LRGT 16-2, LRGT 17-1




Fig. 5




Fig. 6 LRGT 16-1 (without cover plate)

Technical Data / Functional Elements

Key

- ① LED 1, green
- ② LED 2, red
- ③ Code switch

- Ⓐ Joint ring 33 x 39, form D, DIN 7603, 1.4301, bright annealed
- Ⓑ Cover screws (cross recess head screws M4)
- Ⓒ EMC cable gland M 20 x 1.5
- Ⓓ Housing cover
- Ⓔ Measuring length and length of installation
- Ⓕ Terminal strip
- Ⓖ Fixing screws for electronic circuit board
- Ⓗ Functional earth connection
- Ⓘ Seat ring
- Ⓝ Fixing nut for terminal box
- Ⓚ Terminal lugs for electrode lines, functional earth
- Ⓛ Thermal insulation
- Ⓜ Reference tube
- Ⓝ Set screw M 2.5 DIN 913

Installation

Installation notes



Attention

- The seating surfaces and threads on the vessel and mounting flange must be accurately machined.
- Use only the supplied ring joint 33 x 39, form D, DIN 7603, 1.4301, bright annealed.
- Do **not** insulate the threads with hemp or PTFE tape.
- The conductivity transmitter can be installed horizontally or with a vertical inclination. Be sure that the measuring surface is permanently submerged.
- The specified torques must be strictly observed.
- Do **not** lag the terminal box.

LRGT 16-1, LRGT 17-1

- Provide a spacing of **approx. 30 mm** between the lower end of the reference tube and the boiler wall, the smoke tubes and other metallic fittings as well as the low water level (LW).
- Do **not** cut the measuring electrode and the reference tube of the conductivity transmitter.

LRGT 16-2

- Provide a spacing of **approx. 60 mm** between the lower end of the reference tube and the boiler wall, the smoke tubes and other metallic fittings as well as the low water level (LW).
- Do **not** cut the measuring electrode.
- Avoid impacts and shocks to the electrode.



Note

- For the approval of the boiler standpipe the relevant local and national regulations must be observed.
- Several examples of installation are shown on pages 17/18.

LRGT 16-1 (for marine applications)

- Max. admissible length of measurement and installation: 400 mm.
- When installed in steam boilers the conductivity transmitter must be secured against unscrewing.

Mounting conductivity transmitter

1. Check seating surfaces of threads or mounting flange provided on vessel or boiler standpipe (see **Fig. 2, 3, 4**). If necessary re-work the surfaces according to the specification indicated in the drawing.
2. Place the supplied ring joint **A** onto the seating surface **B** of the conductivity transmitter.
3. Apply a light smear of silicone grease to the thread of the conductivity transmitter.
4. Screw conductivity transmitter into thread or flange provided on vessel or boiler standpipe and tighten with an open-end spanner A. F. 41 mm. The torque required when cold is 150 Nm.

Examples of Installation

Conductivity monitoring, direct installation of conductivity transmitter via lateral flanged connection




Fig. 7

R*: LRGT 16-1, LRGT 17-1 R = 30 mm
 LRGT 16-2 R = 60 mm

Conductivity monitoring and continuous blowdown control, direct installation of conductivity transmitter via measuring pot and connection of a continuous blowdown valve




Fig. 8

R*: LRGT 16-1, LRGT 17-1 R = 30 mm
 LRGT 16-2 R = 60 mm

| DN [mm] | A [mm] |
|---------|--------|
| 15 | 182 |
| 20 | 184 |
| 25 | 184 |
| 40 | 189 |

Examples of Installation – continued –

Conductivity monitoring and continuous blowdown control, installation of conductivity transmitter in blowdown line via separate measuring pot




Fig. 9

Key

- A** Ring joint 33 x 39, form D, DIN 7603, 1.4301, bright annealed
- 4** Boiler drum
- 5** Shut-off valve GAV
- 6** Continuous blowdown valve BAE
- 7** Measuring pot
- 8** T-type connector

Tools

- Open-end spanner 18 (19) A. F.
- Open-end spanner 41 A. F.
- Screwdriver for hexagon-socket head screws, size 1.3
- Screwdriver for cross-recess head screws, size 1 and 2

Electrical Connection

LRGT 16-1, LRGT 16-2, LRGT 17-1

The terminal box is screwed to the electrode by means of a self-locking fixing nut.

Before establishing the electrical connection you can turn the terminal box by max. $\pm 180^\circ$ to the desired position (cable outlet).

A flexible multi-core control cable, min. conductor size 0.75 mm^2 can be used for wiring.

Connecting the conductivity transmitter

With the terminal box being open:

1. Undo cover screws **B**, remove cover **D**, **Fig. 5**
2. Detach terminal strip **F** from circuit board.
3. Unscrew the cap nut **N** of the cable gland **C** and take out the lamellar insert **P**, **Fig. 10**
4. Cut off outer sheath of the cable **S** and expose the braided screen **Q** over a length of approx. 10 – 15 mm.
5. Push cap nut **N** and lamellar insert **P** with sealing ring **O** onto the cable.
6. Bend braided screen **Q** outwards at a right angle (90°).
7. Fold braided screen **Q** towards outer sheath, i. e. by 180° .
8. Push lamellar insert **P** with sealing ring **O** into gland body **R**, turn it briefly around both sides of the cable axis and snap anti-rotation element into place.
9. Firmly screw on cap nut **N**.
10. Connect the individual cables according to the wiring diagram to the terminal strip **F**.
11. Re-attach terminal strip **F** to circuit board.
12. Replace cover **D** and fasten the cover screws **B**.




Fig. 10

Key

- N** Cap nut
- O** Sealing ring
- P** Lamellar insert
- Q** Braided screen
- R** Gland body
- S** Shielded cable


Safety power supply unit for LRGT 16-1, LRGT 16-2, LRGT 17-1

To supply the conductivity transmitter with 24 V DC, a safety power supply unit (PSU), e.g. Siemens SITOP power 05, must be used; this must provide a level of isolation against voltages hazardous to touch that at least meets the requirements for double or reinforced insulation as per DIN EN 50178 or DIN EN 61010-1 or DIN EN 60730-1 or DIN EN 60950 (electrically protective separation). The PSU must be equipped with a protective device to DIN EN 61010-1.

Tools

- Screwdriver for cross-recess head screws, size 1
- Screwdriver for slotted head screws, size 2.5, completely insulated to VDE 0680-1
- Open-end spanner 12 A. F.
- Open-end spanner 18 (19) A. F.

Wiring diagram for conductivity transmitter LRGT 16-1, LRGT 17-1



Wiring diagram for conductivity transmitter LRGT 16-2




Fig. 12

Basic Settings

Factory setting

The conductivity transmitter features the following factory set default values:

LRGT 16-1, LRGT 17-1

- Measuring range: 0.5 $\mu\text{S/cm}$ to 500 $\mu\text{S/cm}$ (at 25 °C) **preferred measuring range**
- Temperature coefficient: 2.1 (% / °C)

LRGT 16-2

- Measuring range: 100 $\mu\text{S/cm}$ to 7000 $\mu\text{S/cm}$ (at 25 °C)
- Temperature coefficient: 2.1 (% / °C)

Establishing measuring range and actual value output

To set the parameter of the conductivity transmitter, open the housing and use the 10-pole code switch on the circuit board. The code switch can also be used for adapting the cell constant and initiating a functional test. In the following tables, the factory settings are highlighted in grey.

1. Establish the measuring range (control range) of the conductivity transmitter on the basis of the conductivity range of the steam boiler.
2. Set the desired measuring range via code switch. You can use a ball-point pen to set the code switch.

LRGT 16-1, LRGT 17-1

| Code switch | | | Measuring range ($\mu\text{S/cm}$ at 25 °C) | Current output mA = $\mu\text{S/cm}$ | |
|------------------------|-----------|------------|---|--------------------------------------|---------------------------|
| 1 | 2 | 3 | | 4 mA is equivalent to | 20 mA is equivalent to |
| OFF | OFF | OFF | 0.5 | 0.5 | 20 |
| ON | OFF | OFF | | | 100 |
| OFF | ON | OFF | | | 200 |
| ON | ON | OFF | | | 500 |
| Factory setting | | | | | |
| OFF | OFF | ON | | | 1000 |
| ON | OFF | ON | | | 2000 |
| OFF | ON | ON | | | 6000 |
| ON | ON | ON | | | 12000 |

When the supply voltage is applied (during commissioning) the first output will be 4 mA, then the output current increases until it reaches the actual value.

Basic Settings – continued –

Establishing measuring range and actual value output – continued –

LRGT 16-2

| Code switch | | | Measuring range ($\mu\text{S}/\text{cm}$ at 25 °C) | | Current output mA = $\mu\text{S}/\text{cm}$ | |
|------------------------|-----|-----|--|-------------|---|---------------------------|
| 1 | 2 | 3 | | | 4 mA is equivalent to | 20 mA is equivalent to |
| OFF | OFF | OFF | 100 | 3000 | 100 | 3000 |
| ON | OFF | OFF | | 5000 | | 5000 |
| OFF | ON | OFF | | 7000 | | 7000 |
| Factory setting | | | | | | |
| ON | ON | OFF | | 10000 | | 10000 |
| ON | ON | ON | | 12000 | | 12000 |

When the supply voltage is applied (during commissioning) the first output will be 4 mA, then the output current increases until it reaches the actual value.

Checking temperature coefficient setting T_k

For a linear compensation of the measured conductivity value based at 25 °C the temperature coefficient T_k is set at our works to 2.1 % per °C. Once the service temperature is reached you can check this setting by carrying out a comparison measurement – e. g. as part of the commissioning procedure. If there is a deviation between the indicated conductivity and the measured comparison value, correct the readings of the transmitter by adjusting a lower or higher temperature coefficient. Continue modifying the T_k setting step by step until the indicated conductivity value and measured comparison value agree. Please wait 1 to 2 minutes after each step until the measured value has settled.

| Code switch | | | | Temperature coefficient T_k (% / °C) |
|------------------------|-----------|-----------|------------|---|
| 4 | 5 | 6 | 7 | |
| OFF | OFF | OFF | OFF | 0 (no compensation) |
| ON | OFF | OFF | OFF | 1.6 |
| OFF | ON | OFF | OFF | 1.7 |
| ON | ON | OFF | OFF | 1.8 |
| OFF | OFF | ON | OFF | 1.9 |
| ON | OFF | ON | OFF | 2.0 |
| OFF | ON | ON | OFF | 2.1 |
| Factory setting | | | | |
| ON | ON | ON | OFF | 2.2 |
| OFF | OFF | OFF | ON | 2.3 |
| ON | OFF | OFF | ON | 2.4 |
| OFF | ON | OFF | ON | 2.5 |
| ON | ON | OFF | ON | 2.6 |
| OFF | OFF | ON | ON | 2.7 |
| ON | OFF | ON | ON | 2.8 |
| OFF | ON | ON | ON | 2.9 |
| ON | ON | ON | ON | 3.0 |

Commissioning Procedure

Checking electrical connection

1. Check that the conductivity transmitter is wired in accordance with the wiring diagram (Fig. 11, 12, page 20, 21).
2. Make sure that the mains voltage is the same as indicated on the name plate.

Applying mains voltage

Apply mains voltage.



Note

- To remedy malfunctions that might occur during the commissioning procedure see chapter “Systematic malfunction analysis” on page 28 – 29.

Operation

Correcting the measured value

- If the indicated conductivity reading differs from the measured comparison value check and re-adjust the temperature coefficient setting T_k (see section “Settings” on page 24).
- Only if the temperature coefficient setting is no longer sufficient for the correction should the cell constant be modified.
- If a modification is no longer possible remove the transmitter and clean the measuring surface.

Checking the temperature coefficient setting T_k

For settings and procedure see page 24.

Adapting cell constant

The factory set cell constant is a characteristic geometric quantity of the equipment and influences the calculation of conductivity. However, during operation this constant can drift, e. g. due to dirt accumulated on the measuring electrode.

- Depending on the deviation set code switches 8 or 9 briefly to ON and then back to OFF. Wait for approx. 1 – 2 minutes until the measured value has adjusted itself.
- Repeat this procedure step by step until the indicated value matches the measured comparison value.
- If the conductivity transmitter and the controller are spatially separated the adaptation must be made by a second person or by measuring the current in the transmitter.
- If an adaptation is no longer possible remove the transmitter and clean the measuring surface and/or the measuring electrodes.



Note

The default setting of the cell constant can be restored. For this purpose set code switches 8 and 9 simultaneously to ON. After approx. 1 second set both switches back to OFF. Repeat the procedure described in the paragraph above **Adapting cell constant** until the conductivity reading matches the reference measured value.

Adapting cell constant – continued –

| Deviation of the indicated conductivity | Code switch | | | LED indicator | |
|--|-------------|-----------|--------------------------|-----------------------|------------------|
| | 8 | 9 | Function | green | red |
| Non | OFF | OFF | No change | | |
| Indicated value < measured comparative value | ON | OFF | Cell constant increases | Rapidly flashing | |
| Indicated value > measured comparative value | OFF | ON | Cell constant decreases | | Rapidly flashing |
| | ON | ON | Restores factory setting | Both rapidly flashing | |

Operation – continued –

Functional test

1. To check the functions of the conductivity transmitter set code switch 10 to ON in order to simulate a value that exceeds the measuring range limit and to provide a current output of 20 mA.
2. After finishing the functional test set the code switch back to OFF.

| Code switch 10 | Functional test |
|----------------|--|
| OFF | Normal operation |
| ON | Simulation: measuring range limit exceeded |

LEDs and malfunction indication

The two LEDs in the centre of the electronic insert indicate the status of the conductivity transmitter.

| Normal operation | Green LED | Red LED | Current output [mA] |
|---|-----------|---------|--------------------------------|
| Conductivity 0 to +10 % of measured range | | lit | proportional to measured value |
| Conductivity 10 to +90 % of measured range | lit | lit | proportional to measured value |
| Conductivity 90 to +100 % of measured range | lit | | proportional to measured value |

Flashing LEDs indicate a malfunction.

| Malfunction | Green LED | Red LED | Current output [mA] |
|---|----------------------|----------|---------------------|
| Electrode lines interrupted or measuring surface / measuring electrodes exposed | | flashing | 0 |
| Value below 0 % setting | | flashing | 4 |
| Value above 100 %, e. g. measuring range too small | flashing | | 20 |
| Short circuit electrode lines | | flashing | 0 |
| Temperature in terminal box exceeds 85 °C | flashing | flashing | 0 |
| Lines to resistance thermometer interrupted or short-circuited | flashing alternately | | 0.5 |

Malfunctions

Fault-finding list for troubleshooting

Equipment is not working

Fault: No supply voltage.

Remedy: Apply power and check all electrical connections.

Fault: Electronic insert of the conductivity transmitter defective.

Remedy: Replace electronic insert.

Fault: Mass connection to vessel interrupted – no function.

Remedy: Clean seating surfaces and screw in electrode with metal joint ring 33 x 39, form D, DIN 7603, made from 1.4301, bright annealed. Do not seal electrode with hemp or PTFE tape.

Equipment signals malfunction

LED display: Red LED flashing.

Current output: 0 mA

Fault: Electrode lines interrupted or measuring surface / measuring electrodes exposed.

Remedy: Check connections of the electrode lines (electronic insert, terminal lugs 1 – 4).
Replace equipment if necessary. Check water level and installation.

LED display: Red LED flashing.

Current output: 4 mA

Fault: Value below 0 % setting, e.g. measuring surface / measuring electrodes exposed.

Remedy: Check water level and installation.

LED display: Green LED flashing.

Current output: 20 mA

Fault: Value above 100 % setting, e. g. measuring range too small.

Remedy: Set a larger measuring range.

LED display: Red LED flashing.

Current output: 0 mA

Fault: Short-circuited in electrode lines.

Remedy: Check connections of the electrode lines (electronic insert, terminal lugs 1 – 4).
Replace equipment if necessary.

LED display: Red and green LEDs are flashing.

Current output: 0 mA

Fault: Temperature in terminal box exceeds 85 °C.

Remedy: Check ambient temperature. Make sure it does not exceed 70 °C.

Malfunctions – continued –

Fault-finding list for troubleshooting – continued –

| | |
|------------------------|--|
| LED display: | Red and green LEDs are flashing alternately. |
| Current output: | 0.5 mA |
| Fault: | Electrical connections to resistance thermometer interrupted or short-circuited, thermometer defective. |
| Remedy: | Check thermometer connections (electronic insert, terminal lugs 5 – 6). Replace equipment if necessary. |

Inaccurate readings

| | |
|----------------|---|
| Fault: | Conductivity reading higher than comparison value. |
| Remedy: | During commissioning: Reduce temperature coefficient T_k . During operation: Reduce cell constant. |
| Fault: | Conductivity reading lower than comparison value. |
| Remedy: | During commissioning: Increase temperature coefficient T_k . During operation: Increase cell constant. |
| Fault: | The measurement result can no longer be adjusted by changing the cell constant. |
| Remedy: | Remove conductivity transmitter and clean measuring surface / measuring electrodes. |

Cleaning the measuring electrode

The equipment must only be installed and removed by qualified personnel. For more information see section "Installation" on page 16.

To clean the measuring electrode take the conductivity transmitter out of service and de-install it.

LRGT 16-1, LRGT 17-1

To clean the measuring electrode take the conductivity transmitter out of service and de-install it. Then undo the safety set screw **(N)** and unscrew the measuring tube **(M)** by hand.

LRGT 16-2

Clean the electrode rod and the measuring surface:

- Use a fat-free cloth to wipe off loose deposits.
- Use abrasive linen (medium grain size) to remove encrusted dirt deposits.

Exchanging the electronic insert

1. Unscrew cover screws **B** and remove housing cover **D**.
2. Pull electrode wires from terminal lugs **K** on circuit board. Detach terminal strip **F**.
3. Undo the functional earth **H** connection.
4. Unscrew the fixing screws **G** for the electronic insert and take out the insert. The electronic insert is available as spare part (type LRV 1-40) for LRGT 16-1, LRGT 17-1, type LRV 1-42 for LRGT 16-2.
5. Install the new electronic insert in reverse order.



Note

Please indicate the version and material numbers stated on the name plate when ordering spare parts.

After replacing the electronic insert check the conductivity readings of the controller KS 90-1 by carrying out a comparison measurement.

If you encounter any deviations, correct the cell constant of the conductivity transmitter.

If faults occur that are not listed in the fault-finding list or cannot be corrected, please contact our Technical Services or authorized agency in your country.

Decommissioning



Danger

Risk of severe burns and scalds all over the body.

Depressurise the vessel or measuring pot (0 bar) and make sure that it has cooled down to room temperature (20 °C) before de-installing the conductivity transmitter.

Exchanging the conductivity transmitter

1. Switch off the voltage supply.
2. Unscrew cover screws **E** and remove the housing cover **D**.
3. Disconnect the connecting wires from the terminal strips **F** and pull wires out of the cable gland.
4. Remove the conductivity transmitter.
5. Install and connect the new conductivity transmitter.
6. Switch on voltage supply.

Disposal

Remove the conductivity transmitter and separate the waste materials in accordance with the material specification.

Electronic components (boards) must be disposed of separately.

For the disposal of the conductivity transmitter observe the pertinent legal regulations concerning waste disposal.



GESTRA

Agencies all over the world:

www.gestra.de

Great Britain

Flowserve GB Limited

Abex Road
Newbury, Berkshire RG14 5EY
Tel. 0044 16 35 / 46 99 90
Fax 0044 16 35 / 3 60 34
E-mail gestraukinfo@flowserve.com
Web www.flowserve.com

Singapore

Flowserve Pte. Ltd.

12 Tuas Avenue 20
Singapore 63882
Tel. 0065 / 68 79 89 00
Fax 0065 / 68 62 49 40
E-Mail fcd_gestra_singapore@flowserve.com
Web www.gestra.com

South Africa

Flowserve SA (Pty) Ltd.

Unit No. 1
Director Road
Spartan Extension 2
Kempton Park 1613
Tel. 0027 11 / 9 23 73 00
Fax 0027 11 / 9 74 64 20
E-Mail tvniekerk@flowserve.com
Web www.flowserve.com

USA

Flowserve GESTRA U.S.

2341 Ampere Drive
Louisville, KY 40299
Tel. 001 502 / 267-22 05
Fax 001 502 / 266-53 97
E-mail fcd-gestra-usa@flowserve.com

GESTRA AG

P. O. Box 10 54 60, D-28054 Bremen
Münchener Str. 77, D-28215 Bremen
Tel. 0049 (0) 421 35 03 - 0
Fax 0049 (0) 421 35 03 - 393
E-Mail gestra.ag@flowserve.com
Web www.gestra.de

